

VORTEX OPTICS®

Setting your RZR Zero Stop



Take your mounted scope to the range! You'll need the 2mm hex wrench and enough ammunition to sight in your scope.



Outer Set Screws



Turret Cover



Lock Screws

Step One:

Twist the turret clockwise until you feel a hard stop. (Don't worry if the stop is not exactly at the marked zero).

Step Two:

Loosen the three set screws (don't remove them completely) with 2mm hex wrench. Pull the off cover and set it aside. Some resistance is normal because of the waterproof o-ring seal.

Step Three:

Loosen the lock screws with 2mm hex wrench but don't completely remove them.

Step Four:

Shoot and adjust the windage and elevation until you are satisfied with the zero.

Step Five:

Carefully tighten the lock screws.

Step Six:

Replace outer turret cover and remember slight resistance is normal.

Step Seven:

Line up zero on the cover with the engraved indicator line etched on the bottom of the turret or the body of the scope. Without moving the turret, tighten the set screws.